

# 808nm Conduction Cooled Single Bar Stack (QCW)

#### Introduction

Conduction-cooled single bar array, which can achieve continuous or quasi-continuous high power output, is widely applied in laser pumping, cutting and medical, etc.



## Tech Parameters (25°C)

Conduction-cooled Single Bar Stack(Quaisi- Continuous)				
Parameter		Unit	LDAQ1-0808-100W	LDAQ1-0808-300W
Optical Parameter	Operation Model	-	QCW	
	Center Wavelength	nm	808 ±5	
	Output Power	W	100	300
	Spectral Width	nm	< 5	< 3
	Lighting Unit Qty.	рс	100	62
	Wavelength& Temperature Ratio	nm/℃	0.28	0.28
	Fast Axis Divergence	deg	< 35	< 39
	Slow Axis Divergence	deg	< 10	< 9
	Duty Ratio	%	≤3	<b>≤</b> 4
Electrical Parameter	Threshold Current	А	< 22	< 20
	Operating Current	А	< 120	< 295
	Operating Voltage	V	< 2.1	< 2.4
Thermal Parameter	Operating Temperature	°C	15 ~ 35	
	Storage Temperature	$^{\circ}$	-10 ~ 60	




Add: Shahe Industrial Park, Changping District, Beijing, China
Tel: +86-10-6076 9887 Fax: +86-10-6076 9887-699
Web: www.htoe.com.cn Email: sales@htoe.com.cn







## **Package Information**



#### **Notice**

- 1. Item model notice: LDAQ2( item model)-8080(center wavelength)-\*\*\*\*(output power)
- 2. Package data is only for reference, which can be customized as client's design drawing.
- 3. Please make sure laser diode is operated within 15-35°C, as higher temperature will cause increased threshold current, lower exchange rate and accelerate the aging.
- 4. Please take measure to avoid of condensation, which will cause aging of laser diode.
- 5. For more information, please contact Hi-Tech Optoelectronics Co., Ltd.



Add: Shahe Industrial Park, Changping District, Beijing, China Tel: +86-10-6076 9887 Fax: +86-10-6076 9887-699 Web: www.htoe.com.cn

Email: sales@htoe.com.cn



